

SS500 Compliant Grass Tiles Specification and Installation



Environmentally friendly rubber matting system offering grass reinforcement as well as a tested impact absorbing surface.

Features:

- H.I.C. of 3.0m on grass
- Impact absorbent
- Non-slip surface
- Absorbs shock and noise
- Excellent durability and comfort
- Suitable for all weather and extreme temperatures
- Honeycomb design allows liquid and debris to drain keeping surface dry and clean.

Specification:

Rubber honeycomb tiles:

Tile Size: 1.5m x 1.0m x 23mm thick
Tile Weight: 19kg
Colour: Black

The area covered is secured in place with the use of galvanised or plastic fixing pins
 Allow for 3 no. pins per outer edge of the total carpet area.



sportsequip.co.uk

The Manor, Tur Langton, Leicestershire LE8 0PJ
 tel: 01858 545789 | fax: 01858 545890
 e-mail: sales@sportsequip.co.uk | website: www.sportsequip.co.uk

Boyd Sport & Play Ltd trading as sportsequip.co.uk reserve the right to alter or amend specifications without prior notice and cannot be held responsible for any consequences arising out of errors or omissions. sportsequip.co.uk® and Astroturf® are registered trademarks

INSTALLATION INSTRUCTIONS

Tools Required:

Tape measure, Stanley knife, rubber gloves, hammer, grass edge cutter, spade, cable ties, grass seed, rechargeable drill and 6mm drill bit, and 3 no. edge fixing pins at the rate of 3 no pins per outer edge of carpet area.

1. Mark out the area to be covered with the Compliant Grass Tiles.
2. Compliant Grass Tiles can be laid directly onto existing grassed areas. The area should be filled in if uneven with topsoil and be compact.
3. Sow grass over this area.
4. (OPTIONAL) For soft (boggy) areas lay an open coarse membrane. Leave about 150mm in from the outside edges.
5. Now lay out the Compliant Grass Tiles over the area to be covered, cutting around any equipment or obstacles if necessary.
6. All adjoining edges to be glued. Ensure the tiles are dry prior to gluing. Fasten edges together using cable ties and trim tails.
7. Cut into the ground about 75mm deep along the outside edge of the perimeter area to be covered using a grass edge cutter or similar.
8. Roll back the Compliant Grass Mat. Starting about 150mm in from the outside edge of the mats, use a spade and cut the top turf away in the direction of the 75mm deep cut finishing at the depth. This will leave a wedge shape channel. Continue around the perimeter of the laid mats.
9. Roll the Compliant Grass Mat back and down into the channel and pin the edge through the small holes in the mat and into the ground. Place a small amount of glue into the hole before tapping the pin. Use 1 pin per mat corner and 1 pin midway. You should now have a ramp edge all the way around. Now cover the ramped area with topsoil and seed. Bring the level back up to its original level and flatten.



sportsequip.co.uk

The Manor, Tur Langton, Leicestershire LE8 0PJ

tel: 01858 545789 | fax: 01858 545890

e-mail: sales@sportsequip.co.uk | website: www.sportsequip.co.uk

Boyd Sport & Play Ltd trading as sportsequip.co.uk reserve the right to alter or amend specifications without prior notice and cannot be held responsible for any consequences arising out of errors or omissions. sportsequip.co.uk® and Astroturf® are registered trademarks