

# Practice Turf Installation

## Instructions for Bonding Practice turf Carpet to Base

- Ensure base is clean and free from contamination.
- Roll out carpet to check length and width and that it is square on the base.
- Carefully roll up one half of the carpet to the middle of the base.
- Apply adhesive to the concrete base with a flat or small toothed trowel and immediately roll the carpet into the wet adhesive so it transfers to the carpet. In warm conditions the adhesive will quickly "skin over" resulting in a poor bond. If this occurs, more adhesive will have to be applied.
- Roll the carpet into the adhesive with a lino roller or heavy garden roller.
- Repeat instructions 4 and 5 to the remaining half of the wicket.
- Continue rolling until satisfied the bond is complete.

Trim off any excess carpet with a Stanley knife and straight edge.



**sportsequip.co.uk**

The Manor, Tur Langton, Leicestershire LE8 0PJ

tel: 01858 545789 | fax: 01858 545890

e-mail: [sales@sportsequip.co.uk](mailto:sales@sportsequip.co.uk) | website: [www.sportsequip.co.uk](http://www.sportsequip.co.uk)

Boyd Sport & Play Ltd trading as sportsequip.co.uk reserve the right to alter or amend specifications without prior notice and cannot be held responsible for any consequences arising out of errors or omissions. sportsequip.co.uk® and Astroturf® are registered trademarks