

Instructions for replacing fuse in multibank charger



Locate IEC socket where lead enters the multibank charger



Lift fuse cover from socket and remove

Remove fuse and re-install correct fuse:

Product code: LED/TB/FUSE/5A
Description: ANTISURGE FUSE 5A CERAMIC



Place fuse and holder back into socket and push holder until it is level with the rear of the socket to ensure correct fitment