



Cricket Datasheets

Connecting your Scoreboard to PlayCricket Scorer (Tablet/Phone)

Connecting your cricket scoreboard to the Play Cricket Scorer App found on tablets or phones is becoming increasingly popular. Once connected the scoring app will talk to your scoreboard and automatically update as you score.

To connect follow these steps:

1. Make sure your controller is turned on
2. Ensure your scoreboard and controller are on the same channel and talking to each other.
3. Set up your game on the PlayCricket Scorer App
4. Go to 'Match Settings'
5. Then 'External Scoreboard'
6. Once in the scoreboard settings, make sure 'Manufacturer' is set to 'Generic'
7. Open the 'Devices' tab and select SO Scoreboard from the list of Bluetooth options
8. Your scoreboard will then populate with all the data from PlayCricket Scorer

If the scoreboard does not update, press 'Refresh Scoreboard' inside the scoreboard settings.

Occasionally the PlayCricket Scorer app may lose its Bluetooth connection to the controller. This can be reinstated by following the above steps.

More information can be found on the following Youtube video:

<https://www.youtube.com/watch?v=QSbyDE8HUgs>

In accordance with the Company's policy of continuous development, Boyd Sport & Play Ltd t/as sportsequip.co.uk reserve the right to alter or amend specifications without prior notice. All statements in this datasheet are made in good faith but the Company will not be held responsible for any consequence arising out of errors or omissions.

sportsequip.co.uk

The Manor, Tur Langton, Leicestershire, LE8 0PJ

t: 01858 545789 | f: 01858 545890 | e: info@sportsequip.co.uk

sportsequip.co.uk and Astroturf® are registered trademarks © sportsequip.co.uk 2025

